

# Giverny

Porzellan





## Giverny

Porzellan



Teller 20,5 cm Blau  
AWO609 | 9315121852638 | **EUR 9,95\***




Teller 26,5 cm Blau  
AWO608 | 9315121852621 | **EUR 14,95\***




Schale 20 cm Blau  
AWO611 | 9315121852645 | **EUR 13,95\***



Becher 350 ml Blau  
AWO612 | 9315121852652 | **EUR 9,95\***



Teller 20,5 cm Grün  
AWO614 | 9315121852690 | **EUR 9,95\***



Teller 26,5 cm Grün  
AWO613 | 9315121852683 | **EUR 14,95\***



Schale 20 cm Grün  
AWO616 | 9315121852706 | **EUR 13,95\***



Becher 350 ml Grün  
AWO617 | 9315121852713 | **EUR 9,95\***



Keramikuntersetzer-Set 4-tlg.  
DUO433 | 9315121842929 | **EUR 9,95\***

\*UVP / Spülmaschinen-, gefrierschrank-, ofen- und mikrowellengeeignet. Untersetzer: Ausschließlich Handwäsche empfohlen.